



# **SNOWLINE** <sup>®</sup> **Controller V-100**

Vestas hydromann

Controller V-100  
Start/stop controller for all  
hydraulic roll spreaders.

### Functions

- Starts laying out material while driving.
- Stops laying out material when not driving.
- Lamp that indicates, when material is being spread out.
- Turn on/off for control equipment.
- Easy to mount and to dismount.

### Contains

Controller box.

Wire part with wheel sensor,  
magnets and valve plug.

Hydraulic part with valve block,  
fittings and hoses.

Can be used at:

- 100 - 120 EL -H - MP
- 200 - 300 G - H
- 1500S - 1700S - 2000S
- 200 - 300SL
- SL 10 - 12 - 14 -25

