



WARRANTY 2 YEARS**



CONCRETE MIXER BUCKET WITH SIDE DISCHARGE





CONCRETE MIXER BUCKET WITH SIDE DISCHARGE



Loading



Mixing



Unloading

The **SL MIXING BUCKET** represents the natural evolution of the traditional mixing bucket with central discharge as regards the safety on yard.



The **SL MIXING BUCKET** is equipped with:

- Safety rounded grill with bag breaker
- **BOTTOM** and bolted **HELIX** made of wear steel **HB400**
- Hydraulic motor fully protected
- Automatic turnbuckler
- Electric valve with hydraulic hoses
- Electrical connection kit
- Feeding hoses
- Flat face couplings (only for SSL)
- Hydraulic opening of the bottom through a cylinder with covered rod
- Unloading pipe L=1500 mm
- Attachment to the machine (bolted attachment as standard supply, starting from the model BM 500 SL).

MIXER BUCKET: WHAT ARE ITS ADVANTAGES?

Example of productivity:

BM250 SL 1 m³ = 20 minutes BM600 SL 5 m³ = 45 minutes

M3 Mixer bucket can be attached to any type of earth moving machine:

SKID STEER LOADER BM150SL-BM200SL-BM250SL-BM330SL-BM400SL
 BACKHOE LOADER BM500SL-BM600SL-BM700SL
 WHEEL LOADER BM1100SL
 TELEHANDLER 2-2,5 tons - BM330SL-BM400SL
 3-4 tons - BM500SL-BM600SL
 >4 tons - BM700SL
 EXCAVATOR from 4 tons



TECHNICAL DETAILS

MODEL	Class	Width (mm)	Capacity (lt)	Transmission	Empty Weight (kg)	Full Load Weight * (kg)	Max Flow Rate (lt)	Max Pression (bar)
BM 150 SL	1	1285	150	chain	290	650	60	175
BM 200 SL	1	1490	200	chain	315	795	60	175
BM 250 SL	2	1495	250	chain	415	1015	75	200
BM 330 SL	2	1605	330	chain	435	1227	75	200
BM 400 SL	2	1715	400	chain	460	1418	75	200
BM 500 SL	3	1795	500	chain	695	1895	150	205
BM 600 SL	3	1940	600	chain	715	2155	150	205
BM 700 SL	3	2090	700	chain	765	2445	150	205
BM 1100 SL	4	2160	1100	chain	1030	3670	115	205

* The full charge weight corresponds to the bucket filled to the maximum technically possible load. Eastern Farm Machinery Ltd., 10 Nicholas Beaver Rd., Guelph, On. N1H 6H9, Tel 5197632400, Fax 5197633930, sales@easternfarmmachinery.com